

RK2 Firmware Update Instructions

Product

ReefKeeper 2

Warning

When you update your firmware your settings will get reset. This means that you will have to set your clock, reconfigure your channels, and recalibrate your pH probe if you have one.

System Requirements

PC running Microsoft Windows 98 or above and a serial port (or USB to serial converter).

Instructions

1. Download RK2_v2.x.zip
2. Unzip files onto your desktop
3. If not previously done, double-click on the file "Digital Aquatics One-time Driver Install.exe". This will only have to be installed once on a computer.
4. Disconnect your temperature probe from your RK2.
5. Connect your serial adapter to the PC serial port and to the temp port.
6. Double-click on "ReefKeeper v2.x Firmware Update.exe"
7. Click on the "Go" button, the program will automatically detect the RK2 on the serial port (it could take a minute). Once it is detecting, watch for the "Loading..." screen.
8. After the update happens, the RK2 will start up and you can proceed to configure it.

DO NOT UNPLUG WHILE THE UPLOAD IS HAPPENING OR YOU WILL HAVE TO SEND YOUR UNIT BACK FOR SERVICE!

